



**Bushing kit:** see picture  
2 Stainless steel bushings  
1 stainless steel washer  
2 thin Volvo washers  
2 Volvo clip locks

#### **INSTALLATION OF BUSHINGS:**

The bushing that mounts on the plate should be installed so that the hip of the bushing is sitting on top of the cable end. The factory washer should be installed between the plate and the bushing/cable. The bushing that mounts on the vertical lever should be installed so that the hip of the bushing is holding the cable end against the side to side (vertical) lever so as to keep the cable end in place. Use the thin washer (#2 in the included picture) and the clip (#1 in the included picture) to hold the bushing in place. **!! For 01 and up cars with plastic side to side cable ends !!** : Install the bushing (#4 on included picture) as described above so that the bushing is holding the cable end against the side to side lever. Then install the thick stainless steel washer (#3 on included picture) inside the plastic cable end against the side to side lever, this washer acts as a spacer to fill the gap left from the bushing. Use the included thin washer (#2 on the included picture) and clip (#1 on included picture) to retain the bushing.

1. Clip



2. Thin washer



3. Thick stainless steel washer



4. Stainless steel bushings

