



Directions for installation of Stainless Steel Cable bushings

NOTE: Use and installation of these parts is at your own risk!!

Equipment you will need: <ul style="list-style-type: none">• Large flathead screwdriver• Channel locks or pliers OPTIONAL: <ul style="list-style-type: none">• White lithium grease• sandpaper	Included parts: <ul style="list-style-type: none">• 303 Stainless Steel Bushings
------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------

Expected time to complete: 1/2hour

INSTRUCTIONS:

1. Remove the airbox and any other obstructions
2. Use a large flathead screwdriver to pry off the clips holding the factory bushings in place. Remove the factory washers. Set the clips and washers aside for later as you'll need them.
3. Use the channel locks to remove the factory bushings.
4. Use sandpaper to sand the inside of the cable ends if they are corroded.
5. For the Bushing on the side to side lever install it so the the hip of the bushing is against the lever and retain the bushing with the factory washer and clip. For the bushing that mounts onto the short shifter plate, place it so that the hip of the bushing is on top of the cable end and the washer is between the plate and the cable end/ bushing. If you are not using a short shifter plate then install it the same as the side to side lever.
(If you have white lithium grease use it to lubricate the bushings and the bushing pins.)
6. Place the cable ends back on the the pins and use the factory washers and clips to fasten them.
7. Reinstall Airbox