



Snabb CNC Aluminum Radio Knobs (P2 Fitment)

Tools Needed: None

Thank you for your purchase. Our CNC Aluminum Radio Knobs are very easy to install and look great!

Installation of Snabb CNC Aluminum Radio Knobs:

1. Your radio does **NOT** need to be removed. Simply grab ahold of the factory plastic/rubber knobs and pull towards yourself (away from the radio).



snabb™

PERFORMANCE PARTS

2. Once the factory Knob has been removed, you can see there is a D-shaped pattern on the factory shaft. Line the Snabb Aluminum Knob up with the shaft and firmly press the Snabb Aluminum Knob onto the radio.

****NOTE: Our Aluminum Radio knobs are VERY tight fitting by design. This is to ensure proper fitment while making sure the knob does not fall off during use. You will need to use considerable force to properly install our Aluminum Knobs.**

Should you ever need to remove the knobs, the radio faceplate will need to be removed. Once the faceplate is removed, you can slide 2 screw drivers underneath the knob and pry upwards. Take great care to not scratch the knobs.

